



**Setup Video 5
Prog. Heating Schedule Part 1**

1

To begin programming the Heating Schedule wake up the stat by tapping any button.

Then press and hold the **CONFIRM** button for 3 seconds




Hold down for 3 seconds



2

The Programme (Pr o9) screen will then appear



3

Press **CONFIRM**




4

Press **>**

To scroll through the **HEATING SCHEDULE** options.




5

Choose from either

Option A: 5/2 SPLIT


1 2 3 4 5 6 7
M T W T F S S

Option B: COMPLETE 7 DAY

1 2 3 4 5 6 7
M T W T F S S

Option C: INDIVIDUAL


1 2 3 4 5 6 7
M T W T F S S




6

When your preferred option is flashing on the display

Press **CONFIRM**



For the purpose of this video a **5/2 SPLIT** will be selected.





**Setup Video 5
Prog. Heating Schedule Part 1**

7

When a **5/2 SPLIT** is selected, Weekdays **1-5** (Mon - Fri) are set first followed by an additional Weekend schedule for days **6-7** (Sat - Sun).

8

SET PERIOD 1

To set the start time the first programme stage will be active

Press or

To choose the **HOUR**

Then press

9

SET PERIOD 1

Press or

To choose the **MINUTES**

Then press

10

SET PERIOD 1

Press

To scroll across **HIGH / MID / LOW HEATING LEVELS** to be active during **STAGE 1**

HIGH MID LOW

11

as shown here **SUNNY LEVEL** has been chosen for **PERIOD 1**

High Temperature Level

when the preferred heating level is selected press

12

SET PERIOD 2

To set the time for **PERIOD 2**

Press or


To choose the **HOUR**

Then press




**Setup Video 5
Prog. Heating Schedule Part 1**


13




14




15




16



17



18







Setup Video 5
Prog. Heating Schedule Part 1

19

as shown here
SUNNY LEVEL has been
 chosen for **PERIOD 3**





High
 Temperature
 Level




20


SET PERIOD **4**

To set the
 time for **PERIOD 4**

Press  or 

To choose the **HOUR**

Then press
CONFIRM 



21

SET PERIOD **4**

Press  or 

To choose the **MINUTES**

Then press
CONFIRM 




22

SET PERIOD **4**

Press 

To choose the desired
HEATING LEVEL to be
 active during **PERIOD 4**

Then press
CONFIRM 



23

as shown here
MOON LEVEL has been
 chosen for **PERIOD 4**




Low
 Temperature
 Level



24

For **PERIODS**
5 + 6

If no further modes are
 required for days 1 to 5
 the time setting can be
 left blank for periods
 5 & 6 in the schedule.





**Setup Video 5
Prog. Heating Schedule Part 1**

25

For PERIODS
5 + 6

To leave periods 5 & 6 inactive leave the clock blank on the display.

then press **CONFIRM** ✓

For **PERIOD 5**

26

For PERIODS
5 + 6

and then **CONFIRM** ✓

For **PERIOD 6**

27

Alternatively, if a 5th and 6th period are required, set the time, then choose the desired heating levels for each of the periods, as shown in the previous steps.

Press **CONFIRM** once the final period is set.

28

The display will then move to the **WEEKEND** setup for days 6-7.

29

For the weekend setup, input a 4 or 6 PERIOD schedule for days 6-7 using the steps previously shown.

then press **CONFIRM** ✓

30

As shown on this display, the system will now revert back to **AUTO MODE** - running the set program for that time of day.

AUTO MODE



Setup Video 5 Prog. Heating Schedule Part 1

31

The HEATING SCHEDULE
has now been successfully
programmed.

